
CHNT POWER



QUICK INSTALLATION GUIDE

Wi-Fi Communication Module

SCS100B10-EU

Doc. No.: 9.0020.1290A0

V1.0 · 2026.10

1. Important Safety Instructions

DANGER!

Operators must wear PPE (e.g., a helmet, safety shoes, safety goggles or insulating gloves), and use a safety belt when working at height, in accordance with applicable local laws and regulations, to prevent accidental injuries or fall incidents.

Before installation and electrical connection, ensure the device is free from any damage.

Do not power on the device during installation or cable connection, as this may cause fire, personal injury, or device damage.

WARNING!

All installation and wiring connections must be performed only by qualified and authorized technical personnel.

All cables must be connected in accordance with applicable electrical installation requirements and any local codes.

Failure to follow these instructions and the safety precautions in the quick installation guide and user manual may result in voiding the warranty, product damage, or property loss.

NOTE


Every effort has been made to ensure the accuracy of the contents; however, all statements, information, and recommendations herein do not constitute a warranty of any kind, express or implied.

No part of this manual may be reproduced, transmitted, or distributed in whole or in part without the express written approval of SHANGHAI CHINT POWER SYSTEMS CO., LTD.


This manual is subject to change without prior notice. The latest version is available at https://www.chintpower.com.

2. Product Introduction

2.1 Dimensions




2.2 Main Components




No.	Function	Description
1	USB Interface	Connect to the COM port on the inverter
2	QR Code	Scan to download the MatriCloud app
3	Indicator Light	Indicate the working status of the communication module

3. Installation

1. Remove the dust cover from the COM port on the inverter.




2. Insert the communication module into the inverter's COM port until it clicks into place.



Tip: To remove the module, press the release clip and pull the module out.

4. LED Indicators



LED	Name	LED Status	Status Description
SER	Operation Indicator	Flashing once every 500 ms	Normal operation
		Flashing once every 80 ms	Connected to the app via Bluetooth
		On / Off	Abnormal operation
COM	Communication Indicator	On	Normal communication with the inverter
		Off	Abnormal communication with the inverter
NET	Network Indicator	On	Normal connection to the server
		Off	Abnormal connection to the server

5. Troubleshooting

WARNING

Only qualified electricians or authorized personnel should perform operations that involve opening the inverter cover.

No.	Status	Solution
1	SER indicator light off	Open the inverter cover and use a multimeter to check if the baseboard power supply voltage is 5.0 V DC. If the voltage is normal but the SER indicator remains off, the module is faulty. Please call the after-sales service hotline.
2	COM indicator light off	Check whether the module is securely connected to the inverter. If necessary, open the inverter cover to check if the internal USB connector is loose.
3	NET indicator light off	If the indicator remains off for more than 30 minutes, please call the after-sales service hotline.

6. Communication Module Configuration

After the communication module is installed and powered on, follow the steps below to configure the network settings via the MatriCloud App.

6.1 App Download

Scan the QR code to install the MatriCloud App (Android 7.0+ / iOS 13.0+), then connect via Bluetooth.

6.2 Communication Module Configuration

> **NOTICE**
>
> After the module powers on (SER flashes every 500 ms), if the NET indicator does NOT light up within 40 seconds, please wait 5 minutes before connecting to the MatriCloud App via Bluetooth. Once connected, restart the module through the App to speed up the Wi-Fi network connection.

Before starting, ensure the module is powered on and operating normally, and Bluetooth is enabled on your mobile device.

1. Launch the MatriCloud App and tap **Device Access.** (no account or password required)
2. Tap **Bluetooth Connect**.
3. Locate the target communication module in the device list by matching the last 8 digits of its Serial Number (SN). Swipe left on the device row to open the configuration menu.
4. On the **Terminal Parameter Setting** screen, tap **Basic Configuration**.
5. Tap **Modify** in the **Protocol** row to set the communication protocol.

6. Tap **Smart perception** to identify the protocol automatically, or tap **Add** to configure it manually. Tap **Save** when done.
7. Configure the local Wi-Fi network:


   (a) Tap **Modify** in the **wifi ssid** row and enter your local Wi-Fi network name.


   (b) Tap **Modify** in the **wifi pwd** row and enter the Wi-Fi password.


   (c) Verify that **net** (network setting) is set to **WIFI.**
8. Return to the **Terminal Parameter Setting** screen and tap **Advanced Configuration**. (Enter password 1111 if required)
9. Tap **Modify** in the **mqtt host** row and select the appropriate regional server cluster (e.g., Europe, North America, or Asia-Pacific).
10. Return to the **Terminal Parameter Setting** screen:


    (a) Tap **Save** in the top-right corner to apply the settings.


    (b) Tap **Reboot** to restart the module for the settings to take effect.









3
Bluetooth Connect
Left Swipe To Configure
09071055
Terminal



4
Terminal Parameter Setting
Model: SCS100B10-EU (8MB)
-42 dBm
Connected to Server
Reboot
Save
After the parameters are set and saved, restart the device to be effective.
SN
6XXXXXX09071005
Version
01.06
Basic Configuration
Advanced Configuration
Enable Log
View Log



5
Basic Configuration
Protocol
Modify
wifi ssid
CHINTPOWER
Modify
wifi pwd
****
Modify
net
WIFI
Modify
time zone
Modify
uart0
19200
Modify
period (min)
1
Modify


6
Protocol
Save
Smart perception
It can automatically identify models, addresses and other information, but cannot be identified or failed to identify. Please configure and add manually.
Manual configuration:
The address range is 1-128, and the combined length of all intervals does not exceed 32 and cannot overlap.
Protocol Version: 17
CPS_60KW_G2_8_900
ID Address:
1
1
Add


7
Basic Configuration
Protocol
Modify
wifi ssid
CHINTPOWER
Modify
wifi pwd
****
Modify
net
WIFI
Modify
time zone
Modify
uart0
19200
Modify
period (min)
1
Modify


8
Terminal Parameter Setting
Model: SCS100B10-EU (8MB)
-42 dBm
Connected to Server
Reboot
Save
After the parameters are set and saved, restart the device to be effective.
SN
2XXXXXX08480004
Version
01.06
Basic Configuration
Advanced Configuration
Enable Log
View Log


9
Advanced Configuration
mqtt host
Europe
Modify
mqtt port
1883
Modify
Upgrade
Modify


10
Terminal Parameter Setting
Model: SCS100B10-EU (8MB)
-42 dBm
Connected to Server
Reboot
Save
After the parameters are set and saved, restart the device to be effective.
SN
2XXXXXX08480004
Version
01.06
Basic Configuration
Advanced Configuration
Enable Log
View Log

Contact Us

SHANGHAI CHINT POWER SYSTEMS CO., LTD
Address: No. 5999 Guangfulin Road, Songjiang District, Shanghai, 201616, China
Service Hotline: +86-21-37791222-866300
Fax: +86-21-37791222-866001

Scan to download MatriCloud

© 2026 SHANGHAI CHINT POWER SYSTEMS CO., LTD. All Rights Reserved.
Subject to change without notice.